


1159


COLOURWAYS



FRONT



LEFT END



TOP


COLOUR

1159 Chicane Sports Bag


# 1159

**NOTE:**


The maximum decoration area is a guide only and is greatly dependant on the logo shape.



FRONT



LEFT END




TOP

-----  
EMBROIDERY


1159

**NOTE:**


The maximum decoration area is a guide only and is greatly dependant on the logo shape.



FRONT



LEFT END




TOP


-----  
SUPACOLOUR / PRINT

**NOTE:**


The maximum decoration area is a guide only and is greatly dependant on the logo shape.



FRONT



LEFT END



TOP

-----  
SUPASUB / SUPAETCH / SUPAFLEX

1159

# FABRIC SWATCH

**BLACK/RED**



BLACK



PMS 186 C

---

Pantone colours are provided as a reference only and are based on closest match. Actual product colour may differ. If a precise colour match is required we recommend ordering a sample.