

1212


COLOURWAYS




SIDE



TOP



FRONT




BACK


COLOUR

1212 Ranger Sports Bag

1212




TOP




SIDE

NOTE:

The maximum decoration area is a guide only and is greatly dependant on the logo shape.




FRONT




BACK

EMBROIDERY / SUPASUB / SUPAETCH / SUPAFLEX

1212




TOP




SIDE

NOTE:

The maximum decoration area is a guide only and is greatly dependant on the logo shape.




FRONT



BACK

SUPACOLOUR

1212




TOP




SIDE

NOTE:

The maximum decoration area is a guide only and is greatly dependant on the logo shape.



FRONT



BACK

SCREENPRINT

1212

FABRIC SWATCH

BLACK/BLACK



BLACK



BLACK

Pantone colours are provided as a reference only and are based on closest match. Actual product colour may differ. If a precise colour match is required we recommend ordering a sample.