


1234

COLOURWAYS



TOP




FRONT




BACK

COLOUR

1234




FRONT



TOP

NOTE:


The maximum decoration area is a guide only and is greatly dependant on the logo shape.




BACK

EMBROIDERY / SUPASUB / SUPAETCH / SUPAFLEX

1234




FRONT



NOTE:

The maximum decoration area is a guide only and is greatly dependant on the logo shape.



BACK

SUPACLOUR

1234

FABRIC SWATCH

BLACK



BLACK

Pantone colours are provided as a reference only and are based on closest match. Actual product colour may differ. If a precise colour match is required we recommend ordering a sample.