


1974


COLOURWAYS



FRONT

COLOUR


1974



NOTE:

The maximum decoration area is a guide only and is greatly dependant on the logo shape.


EMBROIDERY / SUPASUB / SUPAETCH / SUPAFLEX



NOTE:

The maximum decoration area is a guide only and is greatly dependant on the logo shape.

SUPACOLOUR









NOTE:

The maximum decoration area is a guide only and is greatly dependant on the logo shape.

SCREENPRINT

1974

FABRIC SWATCH

NATURAL (WHITE)/BLACK		NATURAL(WHITE)		BLACK
NATURAL (WHITE)/NAVY		NATURAL(WHITE)		PMS 2965 C
NATURAL (WHITE)/RED		NATURAL(WHITE)		PMS 186 C

Pantone colours are provided as a reference only and are based on closest match. Actual product colour may differ. If a precise colour match is required we recommend ordering a sample.