

B439


COLOURWAYS



END



TOP







FRONT



BACK

COLOUR

B439





NOTE:

The maximum decoration area is a guide only and is greatly dependant on the logo shape.



EMBROIDERY

B439







NOTE:

The maximum decoration area is a guide only and is greatly dependant on the logo shape.



SUPACOLOUR

B439







NOTE:

The maximum decoration area is a guide only and is greatly dependant on the logo shape.

PRINT

B439



NOTE:

The maximum decoration area is a guide only and is greatly dependant on the logo shape.

SUPASUB / SUPAETCH / SUPAFLEX

B439

FABRIC SWATCH

BLACK



BLACK

Pantone colours are provided as a reference only and are based on closest match. Actual product colour may differ. If a precise colour match is required we recommend ordering a sample.